

# AUTOLIFT SYSTEM

## INSTALLATION MANUAL FOR ADAPTER **DUCATO 244 ALKO**

WATCH ALSO TUTORIAL VIDEO:



Please subscribe to our Youtube channel TESA AUTOLIFT SYSTEM and see all tutorial videos.

## Front right adapter Ducato 244 Alko

Step 1:



Put the adapter most front possible, if necessary remove any sealing material for a perfect adherence, use a bottle jack to stop the bracket in the correct position and make the 8mm side hole then fix with the bolt.

Step 2:



Apply the clamp

**JACK WITH MOTOR TO THE OUTSIDE OF THE VEHICLE AND  
ROTATION REAR**

## Front left Adapter Ducato 244 Alko

Step 1: Use the same procedure of the right adapter



**JACK WITH MOTOR TO THE OUTSIDE OF THE VEHICLE AND  
ROTATION REAR**

## Rear adapter Alko left/right

- Fix the adapter at 34cm minimum from the floor using the 10x30mm bolts.
- The adapters must be positioned and fixed perfectly specular.
- After having fixed the adapters position the link bars over, then make the 10mm holes where will be fixed the jacks.
- Then fix the highjack with the 10x70mm bolts (the bolts must tighten the adapter, the link bar and the jack together).
- The jacks can be rotate front or rear.
- Then adjust the limit switches (see installation manual).





